

The Winterization of tl

Task order	System	Task	Complete
1	Water system	Prior to Haul	
	1	Empty Hot Water tank	
	2	Remove hot & cold from HW Tank and install Cross over to H&C lines (Cross over ahead of Hot Water Tank)	
	3	Take aft screw out of HWT Holder and lift tank and dry underneath with Blue towels	
	4	Empty tanks	
	5	Remove fitting at pump hook up custom fitting (In Bilge behind stairs) to system and put in pink jugs	
	6	Turn on freshwater pump	
	7	Open Kitchen faucet Hot & cold let pink turn real pink	
	8	Open Shower Hot & Cold When Pink close and disconnect shower	
	9	Open Hot & Cold faucet in Head run till pink	
	10	Go to Bow run Deck wash until Really pink	
	11	Go to stern run Deck wash until Really pink	
	12	Shut off Freshwater pump and put 1/2 Gallon of pink into each tank	
	13	Connect compressor to Fresh water pump no more than 35 PSI	
	14	Open Faucet's in same order and blow out Pink	
	15	Disconnect Compressor leave all faucets open Complete	

2	Sump	Prior to Haul	
	1	After Water system is complete remove cover empty (Handheld Battery Pump)	
	2	Remove screen clean and completely dry and clean	
3	Head	Prior to Haul	
	1	Empty Holding Tank	
	2	Close Trough Hull Remove hose at the Pump	
	3	Connect spare Clear hose to Pump put in a gallon of Pink	
	4	Open Raw Water Valve Flush Head until Really Pink	
	5	Reconnect Hose to Through Hull Complete	
4	HVAC	When on Land	
	1	Close Through Hull	
	2	Empty Strainer (Bolt in bottom) reinstall bolt	
	3	Use Jug Pump and fill from Hull fitting at both locations system will drain back to the strainer	
5	Generator	Prior to Haul	
	1	Warm up generator change oil and filter	
	2	Close Trough Hull	
	3	Remove bolt from strainer drain and reinstall bolt	
	4	Fill strainer with green and have 4 Gallons open run generator until green at exhaust is - 40 (Catch in cup and use Hydrometer to check)	
	5	Empty strainer Leave Cover off Complete	
6	Transmission	Prior to Haul	
	1	Check oil change every two years changed in 2020	

7	Engine	Note: if Boat has to be moved day of Haul out Item 1 Must be done in the water and all other items can be performed on shore	
	1	Warm up engine and Change the oil Shell Rotella 18 Litres and Filter Plus 1 litre	
	2	Open 2 Drains in block (will drain for 20 minuets) Close after empty	
	3	Close Through Hull	
	4	Remove Bolt from Strainer empty to bilge re-install bolt	
	5	Fill strainer 1 Gallon and have 15 Gallons of Green open and ready	
	6	Run Engine catch green in exhaust and check with Hydrometer to verify -40	
	7	Remove bolt & Cover from strainer Drain and leave	
	8	Remove Water Pump for Impeller Change at Home every second year Due in winter of 20/21	
	9	Complete	
8	Exterior	After Haul	
	1	Remove air canvas inspect clean and have fixed	
	2	Air cushions and carpets rolled and into sweet cabin	
	3	winterization	
	4	Anchor to home	
	5	Remove all items that obstruct shrink wrap (flag Holder on stern rail Outboard Mount Cameras Anchor Light GPS Antenna)	
9	Interior	After Haul	
	1	Chair backs from salon into aft	
	2	Teak Grates from Head to Home	

10	When On Land	<i>After Haul</i>	
	1	Open Drain and then close all through Hulls	
	2	Blue tarp over forward hatch Use chain to hold front and weight to hold on cabin top	
	3	Install Funnel in Exhaust with cloth	
	4	Leave 110 cord over side prior to shrink Wrap	
	5	After Shrink Wrap Install cloth at Door for Ladder access	
	6	After Shrink Wrap pour a gallon down each Exterior drain Both levels	
11	Batteries	<i>After Haul</i>	
	1	Disconnect Negative off both banks	
	2	Remove Generator Battery & Spare to Home	
	3	Shut off Battery switches all Generator and main	

Give her

The great Cartouche

Notes

[illegible]

1/2 Gallon Pink in each unit

--

a Kiss we are done